



Do NOT use any alcohol or bleach based cleaners / disinfectants on the robot. It will erode away the rubber & discolor the plastic on the robot. If you need something for disinfecting, please contact us.

If it were us – Read Me First!

(if you use these instructions for the Double 3 Robot, you shouldn't need anything else for basic operation)

Over the last couple of years, we've watched a number of clients rent the Double Robotics telepresence device from us and each time we've been present to see the robot – we notice that, even with all the instructions in the box – there is always something the person forgets to put on the robot. So here's a very quick list of assembly steps that we use when using the robot internally or if we are on-site for a rental. **With the new Double 3 head, it's even easier to get going.**

Open the robot box and pull the base unit out and the charging dock.

Take the robot head and attached the head unit to the pole. Secure the head unit using the bolt and the large allen wrench.

Plug the charger into the wall and dock the base unit to top off the robot. Wait about 90 seconds. The head will power itself on.

If the robot isn't connected to a wifi network, you will see a "connect to wifi" screen. Choose the correct network, tap the CONNECT button and enter the password is requested. NOTE: The unit will not work on what is called a "captive portal" where a web page needs to be brought up to accept terms and conditions. You should connect to a wifi network which does not require this.

The robot is ready, when you see the serial number at the top of the screen & 4 icons at the bottom of the screen.

To allow a remote driver to access the robot, have them go to <https://drive.doublerobotics.com> and login with the user ID & password supplied.

If you want to send a limited time visitor pass to someone instead, click on the "user" icon on the robot screen, scan the QR code with your mobile device and follow the on-screen instructions.

You are ready to go!